Read this before you start

HOW TO REMOVE THE SNOWFLAKES

The snowflakes are delicate. Go slowly and gently so they don't break.



1 Find the two tabs
Each snowflake is held to the board by two small tabs, like the one circled.

2 Wiggle the snowflake
Gently rock it back and forth to loosen the tabs. Don't force it, or the edges can bend or break.

3 Push next to the tabs
Gently push on the board beside each tab until the snowflake comes free.

Scan to watch how it's done